

TRW Automotive
Steering & Suspension Systems



Service Bulletin #COL-149

Gen II Remote Actuation Cable Lash

Released March, 2000

This TRW Commercial Steering Division service bulletin has been written to help you repair commercial vehicles more efficiently. This bulletin should not replace your manuals; you should use them together. These materials are intended for use by properly trained, professional mechanics, NOT "Do-it-yourselfers". You should not try to diagnose or repair steering problems unless you have been trained, and have the right equipment, tools and know-how to perform the work correctly and safely.

1. Loosen the nut and lock washer located on the foot pedal assembly.
2. Turn the Hex Stock Fitting so it moves (about 1/8" to 1/4") toward the Foot Pedal Assembly, until some cable slack is noticeable.
3. Fully depress the Pedal.
4. Turn the Hex Stock Fitting so it moves away from the Foot Pedal Assembly. Remove the cable slack until the Cam rotates and comes within 1/8" of making contact with the Pivot Bracket.
5. Release the pedal, hold the Hex Stock Fitting in position, and tighten the Nut and Lock Washer on the Foot Pedal Assembly. Tighten until finger-tight, then turn the nut an additional 1/4 turn with an open end wrench.



TRW Commercial Steering Systems

P.O. Box 60
Lafayette, IN 47902
Phone: 765.423.5377
Fax: 765.429.1868